

# Primer Pens

Use a solution of 70% Isopropyl Alcohol and thoroughly clean the surface. Next, apply the primer to the surface using the cut-out above.

**Crush here to release primer.**



**Foam Tip Applicator**

The clear, colorless primer dries quickly, so to save primer and time, use the cut-out above and pre-mark where you will be placing your studs.

## Directions:

1. Shake the pen well before using.
2. Squeeze the pen 1 inch in from the foam applicator to release the primer.
3. Once the primer has saturated the foam tip apply a thin, uniform coating to the surface using the cut-out above as a guide. This prevents wasting primer by only applying it on the area where the stud will be adhered.
4. Allow to dry before applying your studs. Dry time is about 5 minutes at room temperature.

**NOTE:** Extremely porous surfaces may require a second coat. Be sure to test your surface for compatibility before you begin.

For detailed instructions visit  
[ezsnapdirect.com/support](http://ezsnapdirect.com/support)



0

1

2

3

4

5

*Use this cut-out to apply your primer exactly in the area where you will be adhering your adhesive stud.*

*The built-in ruler to the left can be used to properly space your studs.*

*Use the spacing guide below:*

**3M** Innovation

## For Shade Products:

Window Square Footage:

Over 24 Sq/Ft use = **5 inch Spacing Maximum**

Up to 24 Sq/Ft use = **10 inch Spacing Maximum**

\*\*\* Use two fasteners side by side in the corners

## For RV Skirting:

Do Not Exceed = **5 inch Spacing Maximum**