

Tools Required

- Tape Measure
- Cordless Drill
- Phillips Drill Bit
- Sharp Scissors
- Isopropyl Alcohol
- Cleaning Cloth
- Straight Edge
- Saw to cut PVC Pipe
- Marking Pencil



EZ SNAP™

Customer Support Line

Call Toll-Free 1-877-439-7627

Monday ~ Friday

8:30 to 4:00 PM Pacific Time



For More Information

Call Toll-Free:

1-877-439-7627

1-877-4EZSNAP



EZ Snap® is the #1 Selling RV Skirting in North America

EZ SNAP™

Complete
Instructions
Online At The
Link Below



Full Instructions

ezsnapdirect.com/how-to-install-rv-skirting



EZ SNAP™

RV Skirting Install Tips

TIP 1 Installing Fasteners

1. Using a pencil or similar; mark out your fastener locations. In areas of higher stress, place fasteners closer together. Example: in the corners where the slide-outs meet the trailer, place 2 fasteners side by side in the 90° degree corner.
2. For 3M™ studs, carefully read the install tips shown on the right of this brochure.
3. NEVER exceed the maximum spacing. The closer the spacing, the better the performance; especially in high winds.

TIP 2 Installing Skirting

1. Pre-planning the install = No Surprises!
2. It's much easier to install with a partner.
3. When pushing the fabric over the pins, push straight to avoid snapping the pin.
4. Push the fabric to the very base of the pin using the end of the removal tool. This exposes all of the pin's teeth so that the cap's teeth can lock on completely.

TIP 3 Heaters under R.V.

1. Electric heaters ensure the area enclosed by the skirt will never go below freezing.
2. Use 1 heater at each end for long RVs.
3. Heater should have a thermostat control and a overheat/tip over safety switch.
4. Place your heaters on a stable, flat and fire resistant surface.

TIP 4 Pipe Clamp System

1. EZ Snap's pipe clamp system is a proven way to finish and secure the bottom of your skirting. When correctly installed it not only looks great, but provides a stable perimeter framework against wind.
2. Number the pipe lengths and connectors for quick & easy reassembly.
3. Place EZ Snap® pipe clamps every 2 feet for the best performance against high winds.
4. Heavy objects placed behind the skirting at the corners and down sides prevents wind movement of the skirt & pipe frame.

TIP 5 Extra Tips & Ideas

1. The smooth side of the fabric faces out.
2. Seal up areas where wind can get in using Gecko Velcro. Eliminate flapping and parachuting of fabric in wind storms.
3. Use extra fasteners in high stress areas.

TIP 6 Cleaning & Storage

1. Inspect skirting frequently and address any loose or damaged areas.
2. Avoid harsh cleaners or solvents.
3. Fabric must be fully dry before storing.
4. Mark on RV & skirting where the starting point is to make it easier to re-install.
5. Remove skirt by unsnapping the pin base from the stud using the removal tool.

** Important **

Do Not install 3M adhesive studs below 15°C/60°F.
Ideally 21°C/70°F or warmer.

- Adhesive will only stick to surfaces that are clean, smooth and flat.
- Clean surface with a 50/50 solution of isopropyl alcohol & water, to remove all film, dirt or oxidization.
- Use 3M Primer when in doubt.
- Press studs into place using a minimum of 15 lbs of pressure.
- Spacing for adhesive fasteners is a MAXIMUM of 5 inches or 10 inches Max if used with a center screw.

EZ SNAP™ 3M Adhesive Stud Bonding Time



IMPORTANT

EZ Snap fasteners are designed to work with the EZ Snap RV Skirting fabric. Using other fabrics will void your warranty.

Complete
Instructions
Online At The
Link Below



Full Instructions

ezsnapdirect.com/how-to-install-rv-skirting

Cool your RV
this Summer using
EZ Snap® Exterior RV Shades.

Blocks 90% of the sun's heat,
without blocking the view.